

BARRICADE®

SPREADER SETTINGS

SPREADER MODEL	LOW RATE 3.1 lbs/1,000 sq. ft.	MEDIUM RATE 3.5 lbs/1,000 sq. ft.	HIGH RATE 4.7 lbs/1,000 sq. ft.	HEAVY RATE 7.1 lbs/1,000 sq. ft.
The Andersons LCO-1000	K 1/2	L	M 1/2	P
The Andersons Yard Star 2150	13 1/2	14	15 1/2	18
Agri-Fab Broadcast (1-10)	3 1/2	4	5	7
Agri-Fab Drop (0-10)	3 1/2	4	5	7
Brinly 20 Series Push Broadcast (0-30)	13 1/2	14	15 1/2	18
Chapin Broadcast (0-30)	13 1/2	14	15 1/2	18
Craftsman Broadcast (1-10)	3 1/2	4	5	7
EarthWay Broadcast (0-30)	13 1/2	14	15 1/2	18
EarthWay Drop (0-30)	13 1/2	14	15 1/2	18
EarthWay 3400 Hand Spreader (1-3)	1	2	3	-
Precision Broadcast (1-10)	3	3 1/4	3 1/2	7
Precision Drop (1-10)	1 3/4	2	2 1/4	5 1/2
Scotts Broadcast (2-15) (Includes EdgeGuard, Elite, Standard, Basic, LawnPro & Speedy Green 1000 - 3000)	4	4 1/2	5 1/2	7 1/2
Scotts Drop (Accugreen 1000 - 2000 & Classic)	6 1/4	6 1/2	7 1/2	9 1/2
Scotts Wizz Hand Broadcast Spreader	4 1/2	5	6	8
Scotts Hand-Held Broadcast (Handy Green, Easy)	2	3	4	5
Spyker Broadcast	4.9	5	5.5	6.4

Note: These spreader settings were established using standard equipment available from the spreader manufacturer at swath widths and speeds typically used within the industry. Many variables such as walking speed, terrain, particle size, density, and spreader condition can affect these settings. These suggested settings are estimations based on past experience and testing. They are not intended to replace calibration.

For additional questions, contact us at help@andersonshomeandgarden.com